
PART NUMBER	DESCRIPTION
BREAKER -- PANEL	CONTROL PANEL BREAKER SPECIFY AMPERAGE
FAN 5	REPLACEMENT FAN 5" AXIAL 120v
FILTER 5 METAL	FILTER 5" METAL REPLACEMENT
1218 HEATER ONLY	HEATER CORE ONLY FOR TRADEWINDS
SWITCH 120V HA	120 V HIGH AMP TOGGLE SWITCH
SWITCH MOM	REPLACEMENT SWITCH MOMENTARY PUSH
TIMER BOARD	TIMER BOARD ZTIMER100
POWER CORD	POWER CORD 120V